

iTruss



A few simple selections with the iTruss App and you will have the information you need for your current or upcoming project.

Choose Any 3 Parameters and iTruss gives you the 4th.

Select LOAD DISTRIBUTION

There Are 5 Load Types

Uniformly Distributed
Center Point Loads
Third Point Loads

Quarter Point Loads
Fifth Point Loads

SPAN (Feet)

Specify the Span of The Truss

Choose from 5 to 70 feet in multiples of 5.

LOAD PER (pound)

What Is Your Load?

Find your load capacity or enter using the iTruss load calculator.

TRUSS SELECTOR

The Right Truss For the Job

Find the load capacity for your truss or find the best possible truss option for your next project.

THE DISTRIBUTION selector

THE SPAN selector

THE LOAD calculator

iTruss can get you
INSTANT
results on the
many
TRUSS OPTIONS
that are **RIGHT**
for your Project.

Need other
assistance or
information?



XSF

xsftruss.com